



## Moulding and Trim Installation Tips

1. Acclimatize your wood to the surroundings of the normal living conditions of your home. The wood should be set in the home for at least 24 hours prior to installation to allow the moisture content of the wood to adjust to these conditions
2. Paint or stain all exposed surfaces prior to installation. It is much easier and less time consuming than doing it after installed
3. "Measure Twice, and Cut Once"
4. Corner blocks and plinth blocks should be installed before casing and baseboards
5. Crown Mouldings are best cut with a powered miter saw. When measuring for a miter cut, we recommend marking the top of the moulding at the back. Place the crown upside down against the back fence of the saw. Position the saw at 45 degrees and make the cut
6. Counter sink all nail heads and touch up with matching putty.